

37mm & 50mm Insert fit up clocks



These clocks have a white fork shaped lug between the winder and the clock case designed to preserve the battery before installation.



When fitting the clock into timber etc.

REMOVE the WHITE LUG FROM the clock before measuring and making the hole that you are going to fit the clock into.



This will ensure a snug fit.

If you leave the lug in, the clock will be too loose a fit when the lug is removed and fall out of the hole.